



The COMTESSA project: Tomography of artificial SO₂ plumes with multiple SO₂ cameras for improving our understanding of plume dispersion and turbulence

A.S. Dinger^{1,2}, K. Stebel¹, M. Cassiani¹, A. Kylling¹, I. Pizzo¹, N. Schmidbauer¹, H. Ardeshiri¹, S.-Y. Park^{1,3}, A. Stohl¹

¹ Norwegian Institute for Air Research, Kjeller, Norway

² Institute of Environmental Physics, University of Heidelberg, Heidelberg, Germany


³ Institute of Environmental Studies, Pusan National University, Busan, Republic of Korea



Experiment

Controlled release of trace gas SO₂ from tower

- Observation of SO₂ column densities from multiple viewing directions using SO₂ cameras (both UV and IR)
- Observation of atmospheric conditions on towers and tethered balloon H₂O and CO₂ concentration (gas analysers) Boundary layer structure (PTU sonde) Wind field (sonic anemometers)



SO₂ Cameras




Fig: SO₂ camera image of Mt. Etna

SO₂ cameras deliver SO₂ column density images based on measured images of backscattered sunlight at different wavelengths. A set of 9 SO₂ cameras was developed to meet the requirements of COMTESSA in respect of spatial and temporal resolution.




Fig: new SO₂ cameras

	6 x UV	3 x IR
Camera Model	PCO.ultraviolet (dual camera)	Xenics Gobi-384 (triple camera)
Wavelength Bands	310 & 330 nm	8.6, 10 & 11 μm
Max. frame rate [Hz]	7.3	84
FOV [°]	14.7 x 11.1	13.7 x 10.3
Resolution [pixel]	1392 x 1040	384 x 288
Focal Length [mm]	25	40
Weight [kg]	8.3 + 11.6	7.5 + 11.7
Dimensions [cm]	21.5 x 21.5 x 29 28 x 25 x 45	21.5 x 23 x 26 28 x 24.5 x 40

Camera Observations and Modelling of 4D Tracer Dispersion in the Atmosphere

- Andreas Stohl (ast@nilu.no)
- 1/11/2015 – 31/10/2020
- Experiments: every year in spring & summer
- Military facilities in Norway
- High-resolution 4D tracer concentration field

COMTESSA's vision is to elevate the theory and simulation of turbulent tracer dispersion in the atmosphere to a new level by performing completely novel high-resolution 4D measurements.

Goals

- | SO ₂ Camera technique | Tomography | Turbulent dispersion |
|---|---|--|
| <ul style="list-style-type: none"> Validation of SO₂ retrieval Comparison of UV and IR imaging | <ul style="list-style-type: none"> 3D reconstruction of SO₂ plume 3D optical flow analysis | <ul style="list-style-type: none"> Richardson-Obukhov constant Parameterizations for Lagrangian models |

Atmospheric boundary layer

- Test of Richardson-Obukhov law
- Relative dispersion and meandering of plume and puffs
- Statistics of velocity vector field and scalar concentration field
- Two-point concentration structure function

Modelling

Large Eddy Simulations

LES are used to examine the characteristics of the scalar field dispersing from a localized small source under a wide range of atmospheric boundary layer conditions




Fig: Low resolution simulation of the dispersion from a continuous tracer release in a neutrally stratified boundary layer generated in a wind tunnel.

Radiative Transfer Simulations




Fig: Intensities at 310nm (left), 330nm (middle) and apparent absorbance (right) as seen from locations A, B, C

Wavelength-selective intensity images as seen by the SO₂ cameras of the above concentration field are simulated using libRadtran and MYSTIC.





Fig: Geometry of cameras, plume (green) and sun (yellow)

Tomographic 3D reconstruction

Poster X5.492 Thu 17:30-19:00: Tomographic iterative reconstruction of a passive scalar in a 3D turbulent flow

Fig: 2D Reconstruction of the integrated concentration field of the above LES. The phantom (upper panel) was forward projected to a sinogram (middle panel). The latter was then used for the reconstruction of the concentration field (lower panel)



Further Reading

Tracer experiments: Hanna 2010 16th Conference on Air Pollution Modelling
SO₂ plume imaging: Platt et al. 2015 J. Vol. Geo. Res (300) 7-21
Radiative Transfer: Emde et al. 2016 Geosci. Model Dev., 9, 1647–1672, 30
Buras. and Mayer 2011 J. Quant. Spectrosc. Ra., 112, 434–447

Acknowledgment



This project has received funding from the European Research Council (ERC) under the European Union's Horizon 2020 research and innovation programme under grant agreement No 670462.

Interested in knowing more?

Don't hesitate contacting us
asd@nilu.no